

## MITSUBISHI TRACK LOADER SERIAL NUMBERS

### BS3D (DD)

1972 10001 TO 12154  
1973 12155-  
1974 -  
1975 -

### BS3D-S (DD/SUPER)

1972 20001 TO 20522  
1973 20523 -  
1974 -  
1975 -

### BS3E (DD)

1975 10001  
1976 - TO 10888  
1977 10889 TO 11160

### BS3E-S (DD/SUPER)

1975 30403 -  
1976 -  
1977 30001 -

### BS3F (DD)

1977 001 TO 304  
1978 305 TO 907  
1979 908 TO 1460  
1980 1461 TO 1829  
1981 1830 TO 2004  
1982 2005 TO 2112  
1983 2113 -

### BS3F-S (DPS/SUPER)

1977 600001 TO 600095  
1978 600096 TO 600244  
1979 600245 TO 600364  
1980 600365 TO -

### BS3F (DPS)

1977 500001 TO 500458  
1978 500459 TO 501013  
1979 501014 TO 501431  
1980 501432 TO 510674  
1981 501675 TO -

### BS3F-S

1977 100001 TO 100196  
1978 100197 TO 100480  
1979 100481 TO 100733  
1980 100734 TO -

